

ESCATEQ Tampone tipo V - 10 pezzi cm 60

Codice del prodotto: EQ801022
Disponibilità: 1

Prezzo: € 441,64

Tax Ex: € 362,00

Short Description

Lavaggio manuale delle scale mobili

Descrizione

**TAMPONE tipo "V" - Confezione da 10 tamponi da 60 cm.
per usarlo serve il Telaio Esca Teq**

Pulisce la scala mobile in pochi minuti

Esca-Teq economico sistema per pulire la scala o il tappeto mobile.

VANTAGGI:

- una sola persona operativa
- non è necessario fermare la scala mobile
- nessuna fonte di alimentazione esterna
- il design leggero lo rende facile da trasportare e semplice da immagazzinare
- l'ingegnoso tampone in schiuma pulisce le macchie più difficili in modo delicato ed efficace
- il tampone può essere lavato e riutilizzato per almeno 10 volte.

CONFEZIONE: scatola da 10 tamponi

[Link Depliant](#)

[Link Domande frequenti](#)

[youtube url="https://www.youtube.com/watch?v=PeTJpVWY1hc&feature=youtu.be "]

Accessori complementari

Accessori complementari:

- Clean-Teq detergente speciale appositamente formulato per i tamponi Escq Teq.
- Jerrycan tanica vuota per corretto dosaggio del prodotto Clean-Teq.
- Fit Card - dima per verificare le scanalature della scala mobile in "V" o "W".

ISTRUZIONI PER L'USO



ESCATEQ
escalator cleaning tools

ESCALATORS GET DIRTY,
ESCATEQ MAKES CLEANING THEM EASY

1



Block the running escalator opposite to the side you are cleaning.

2



Mix solution 10 parts water, to 1 part Clean-TEQ.

3



Pour the diluted solution into the trough. Do not overfill.

4



Mount pad to device.

5



Allow the cleaning pad to absorb the solution.

6



Place the device onto the moving treads, allow it to align with the combs and drop into place.

7



Tilt the device back and then forward, to help it align with the tread groves.

8



Hold the device in place with light downward pressure.

9



Remove the dirty pad carefully.

10



Rinse pads using moderate water pressure.

11



Replace pads when they become damaged or worn.

12



Dry & re-use pads.

ESCALATOR CLEANING FREQUENCY

Traffic	Location	Recommendation
↑↑↑ HIGH	Airports & Subways	Daily
↑↑ MEDIUM	Shopping Malls & Casinos	Bi-Weekly (twice a week)
↑ LOW	Hotels & Office Buildings	Weekly

Important: Keep fingers, loose clothing, shoe laces, hair, jewelry etc. away from the device and the escalator treads during use. Do not stand or step on the device while it is in operation. The escalator must be dry before allowing passengers back on.

Visit escateq.com for more information or email us at info@escateq.com Copyright 2019 ESCATEQ BV. All rights reserved.

VEDI COSTO DI UTILIZZO

Cleaning your escalators over 100 times per year with Tread-TEQ can cost less than having them cleaned once a year by an outsourced escalator cleaning company!

	Once a week 52 cleanings per year	Twice a week 104 cleanings per year	Every day 365 cleanings per year
Cost per Cleaning	€ 9.21	€ 7.39	€ 5.99
Annual Cost	€ 478.92	€ 768.56	€ 2,186.35

IMPORTANT: See calculations and disclaimer page for more details. Calculations portrayed are all estimates. An outsourced annual restorative cleaning cost of €1200.00 was used for this comparison, your costs may vary. Estimates portrayed are based on a 1000mm escalator. 800mm and 600mm escalators will cost less.

Product Gallery

